



TEIKO®





- CZE** MONTÁŽNÍ A UŽIVATELSKÝ NÁVOD
NOHY
- SVK** MONTÁŽNY A UŽIVATELSKÝ NÁVOD
NOHY
- ENG** INSTALLATION AND USER MANUAL
LEGS
- DE** BEDIENUNGS- UND MONTAGEANLEITUNG
FÜSSE
- HUN** ÖSSZESZERELÉSI ÉS HASZNÁLATI ÚTMUTATÓ
BURKOLÓPANELEK KÁDAKHOZ
- POL** INSTRUKCJA MONTAŻU I UŻYTKOWANIA
OBUDOWY DO WANIEŃ
- РУС** ИНСТРУКЦИЯ ПО МОНТАЖУ И ИНСТРУКЦИЯ ПОЛЬЗОВАТЕЛЯ
НОЖКИ



1



	X = ... cm		X = ... cm
Alea / Alea-S	30 / 20	Korfu	32
Asuán	38	Kréta	35
Atlanta	38	Medea 150	39
Bajkal	32	Medea 160	41
Barbados	38	Medea 170	40
Canaria	38	Naxos / Naxos-R	34 / 34
Elba	38	Samos	33
Etna	45	Spinell 160	35
Ibiza	38	Spinell 180	33
Jáva	43	Sumatra	32
Klasik 120	20	Tahiti	40
Klasik 150	30	Afrodité	40
Klasik 160	38	Borneo-O	36
Klasik 170	40	Borneo-R	36
Klasik 180	35	Malaga	39
Madeira	40	Odessa	45
Mallorca	39	Pireas	39
Malta 180	37	Rhodos 185	36
Malta 190	38	Rhodos 195	39
Orient	47	Vela	34
Palma	42	Columba 160	35
Panama	38	Columba 170	40
Tenerife	35	Columba 180	41
Bodam	39	Columba 190	47
Capri	38	Auriga	33
Cejlon	39	Corona 180	39
Diamant	37	Corona 190x80	38
Florida	33	Corona 190x90	38
Island	34	Ara	38
Kassandra	34		

2**3****4****5****6**